




## MS1-Extra and MS2-Extra

**LS2 COPs:** (Type shown here are those with the heatsink on the top. There is another LS2 COP without the heatsink that's not as powerful but works the same. There is also an LS1 COP which is a 2-wired device and not worth using)



## LS2 COP

(Looking into connector with heatsink facing up)



**Dwell for these COPs are:**

**Cranking = 6.0mS**

**Running = 5.0mS**

[www.ExtraEFI.co.uk](http://www.ExtraEFI.co.uk)